

Jan 2025 -

Features: User driven

- * ** User Story 4361 ** Add eye to eye measurement to the spring rater software
- * ** Development Task 4852 ** Create Single Shock Durability Command
- * ** User Story 4842 ** durability feature that will run and monitor Multiple shocks
- * ** User Story 4882 ** Durability software features
- * ** User Story 4901 ** Software Support for Nagara Switch Dyno

Enhancements: User driven

- * ** User Story 4884 ** SR17 Spring software Ver 24.6.14 RD box default to checked
- * ** User Story 4895 ** if you set filters, it goes back to default when you close program
- * ** User Story 4850 ** warning if you forget to save test after modifying

Bug Fixes:

- * ** Bug 4734 ** "Speed Must Be Greater Than Zero" Message on File Load
- * ** Bug 4848 ** Rater Software Misbehaves after Test Abort
- * ** Bug 4883 ** SR17 Spring Software Ver 24.6.14 The Zero Sensors do not work in a useable manner
- * ** Bug 4888 ** data file from older Probe version will not open in 24 6 14 1918
- * ** Bug 4892 ** Test Speed Edit Box Broken When Rotary Dyno Not Connected
- * ** Bug 4893 ** Wave form will not hold in live mode
- * ** Bug 4896 ** Validation Not Showing in Legend
- * ** Bug 4900 ** High Speed La 2 NDrives-2IO Does not work
- * ** Bug 4904 ** Raw Velocity Still has Velocity Filter Applied
- * ** Bug 4905 ** Report Plot never returns to page 1 after pushed to page 2

Previous - June 28, 2024

CTW Automation presents: release notes for Probe© software version 24.6.14.1015

- * ** Feature 4798 ** Custom Waveform with Analog Output Control
- * ** Feature 4826 ** Automated Dyno Tab
- * ** User Story 4829 ** manual rod force tests
- * ** User Story 4831 ** a print option under the FILE menu
- * ** User Story 4832 ** make timed warm up work without a temp channel
- * ** User Story 4838 ** Cleanup spring rater options
- * ** User Story 4841 ** remove limits on number of cycles that can be run in a test command
- * ** User Story 4845 ** software acts sluggish after 10,0000 cycle test.
- * ** Bug 3250 ** Secondary axis looks like negative values
- * ** Bug 4834 ** Automated Crank live motion button needs disabled.
- * ** Bug 4837 ** Spring Rater Too much data is clipped in 2024.2.14
- * ** Bug 4839 ** rate start/end does not seem to work
- * ** Bug 4840 ** question about spring rater data.
- * ** Bug 4843 ** "Reset Machine" can cause motion on RD
- * ** Bug 4844 ** Selector missing in live data tab
- * ** Bug 4849 ** Read Average Constant not saving a constant to file
- * ** Bug 4853 ** "Primary Analog in not Open" While Open

www.ctwautomation.com



